

Installation of Quantis drivers and libraries

Jaroslaw Miszczak

23/03/2011 (v.0.02)

1 Device drivers

Note: In the following instructions Quantis-v11.01.12 should be replaced by the appropriate directory depending on the software package you are using.

1.1 PCI and PCI-express version

1. Install module-assistant package

```
apt-get install module-assistant
```

2. Prepare your system for module compilation

```
m-a prepare
```

3. Unpack the Quantis software package and go to

```
Quantis-v11.01.12/Drivers/Unix/QuantisPci.
```

4. Compile the module

```
make
```

5. Install the module

```
make install
```

and check if the module was installed properly

```
find /lib/modules/ -name quantis_pci.ko
```

6. Make sure that the drive will be loaded during the next boot

```
echo "quantis_pci" >> /etc/modules
```

7. Follow instructions in Section 1.3.

1.2 USB version

1. Install libusb and libusb-dev packages

```
apt-get install libusb-1.0-0 libusb-1.0-0-dev
```

2. Check your device with lsusb

```
lsusb -d 0aba:0102 -v or lsusb -v | grep Quantis
```

3. Follow instructions in Section 1.3.

1.3 Device permissions

1. Make sure that the plugdev group exists

```
cat /etc/group | grep plugdev
```

2. Add user to the plugdev group

```
usermod -G plugdev -a LOGIN,  
where LOGIN is the login name of the user
```

3. Copy file

```
Quantis-v11.01.12/Drivers/Unix/idq-quantis.rules, to /etc/udev/rules.d/ directory  
and reload the UDEV rules  
udevadm control --reload-rules
```

2 Libraries

1. Unpack distribution files from Quantis-v11.01.12/Packages/Linux to a selected directory,

e.g /usr/local/IDQ/Quantis

```
mkdir /usr/local/IDQ
```

```
tar xjvf QuantisRNG-2.5.0-Linux-amd64.tar.bz2
```

```
mv QuantisRNG-2.5.0-Linux-amd64 /usr/local/IDQ/Quantis
```

After this step the EasyQuantis applicaiton shoul be in

```
/usr/local/IDQ/Quantis/bin/EasyQuantis
```

2. Copy Quantis.h and DllMain.h from

Quantis-v11.01.12/Libs-Apps/Quantis

to

```
/usr/local/IQD/Quantis/include
```

3. Add /usr/local/IDQ/Quantis/lib (or /usr/local/IDQ/Quantis/lib64) to /etc/ld.so.config
or some file which in included by this file e.g /etc/ld.so.conf.d/quantis.conf

4. Update the loader cache

```
ldconfig
```